

**RICE Hydro, Inc.**  
**3500 Arrowhead Drive**  
**Carson City, NV 89706**  
**800-245-4777**

## **Installation and Assembly Instructions** **3B-Pressured Accessory Tank**

### **Assembly Parts Included:**

- (1) 20 gallon tank in mounting bracket with hose assembly
  - (1) ¾" Inlet assembly garden hose swivel
  - (1) 1" x 90 degree Hosebarb Connector
  - (1) Hose clamp
- 

### **Mounting tank bracket to Pump Frame:**

Mount the 3B-Pressured tank assembly bracket on the outside of pump frame, aligning the wide angle feet with the pre-drilled frame holes. When installing with a Wheel and Handle kit, place handle holes to the inside of the pump frame. Use (4) 5/16 x 1 & ¾" Hex Bolts with washers to secure in place.

**Use pipe sealant or Teflon tape on all fitting connections to ensure a tight seal.**

### **Connecting tank outlet to Pump inlet piping:**

Suction feeding hose from pump to tank, is pre-assembled and connected to the bottom of the tank. Screw the 1" x 90-degree hosebarb provided into the inlet piping of pump. Slide hose with clamp over inlet hosebarb and tighten, to secure in place.

### **Tank Inlet Hookup:**

Connect nipple and hose swivel assembly to the tank inlet port on the upper side of tank where the pressure valve and float assembly are already internally attached.